

Vehicle Maintenance Guide

Oil Change Procedure

1. Drain old oil from engine
2. Replace oil filter
3. Add 5.5 quarts of synthetic 5W-30 oil
4. Check oil level with dipstick